



ADDENDUM No. 1

03/27/2025

PROJECT: BSA Hospital PET/CT Infill
1600 Wallace Blvd.
Amarillo, TX 79106

DATE: 03/07/2025
PROJECT NO.: 22418

The following items take precedence over the drawings and project manual for the above-named project and in closing a contract shall become a part of the contract documents.

Where any item called for in the specifications or indicated on the drawings, is supplemented here, the original requirements remain in effect. Consider all supplemental conditions as added to the specifications and drawings.

Where any original item is amended, voided or superseded here, the provisions of such items not specifically amended, voided or superseded remain in effect.

ITEM #1: Sign-In Sheet – The sign in sheet from the Pre-Bid Meeting is attached for reference.

ITEM #2: Taxes – To clarify, this project is NOT tax exempt. The Contractor shall include all applicable taxes for the project.

ITEM #3: Wall Panels – On the Drawings, on elevations 16/A5 and 20/A5, replace “FRP” with “WP1”. In the Project Manual, Section 102600.2.6,A,2 change “.06” to “.04”. All WP# material to be .04” thick. In Holding Rooms 112, 113 and Dose Rooms 115, 117, 119, and 120 install WP3, which is to be added to the Finish Schedule as indicated below. In these rooms WP3 is to be installed up to 50-1/4” a.f.f. except at millwork/sink walls where it shall extend higher. Refer to the extent of WP3 on these walls in the attached, revised A6 Sheet. In Toilet Rooms, the Wall Panel is to be WP2 as indicated on the ID Sheets, not WP1 as indicated in the Finish Schedule.

Wall Protection	WP1	Inpro, Rigid Plastic Wall Panel, Eggshell #0111, .04" thickness (install railroaded with 1/8" seams sealed with caulk to match Eggshell #0111) (trim with J-trim in Eggshell #0111 color)
	WP2	Inpro, Rigid Plastic Wall Panel, Woodland Sugar Maple #0548, .04" thickness (install railroaded with 1/8" seams sealed with caulk to match Camelback #0253) (trim with J-trim in Camelback #0253 color)
	WP3	Inpro, Rigid Plastic Wall Panel, Glimpse #5Z112, .04" thickness (install railroaded with 1/8" seams sealed with caulk to match Khaki Brown #0118) (trim with J-trim in Khaki Brown #0118 color)

ITEM #4: Lead Shielding – To clarify, lead shielding on the walls is only required to extend to 7'-0" per the physicist's report. It is noted in the drawings to extend the 1" thick shielding around the dosing rooms to 8'-0", but that was based on our understanding that plywood lead shielding came in standard 4'x8' sheets. It would be permissible to install that shielding to 7'-0" and furrout above this if it is more economical. Additionally, the design team would be open to other methods of providing the 1" lead shielding along these walls (lead-bricks) as long as the Contractor takes all responsibility for that lead shielding design ensuring that it meets all the same criteria of what is in the Contract Documents. This would include at a minimum, providing the 1-hour rating where required, the overall thickness of the wall and location of the wall does not change, the Contractor would take all responsibility for providing Sealed Engineered Drawings for a delegated design, and the overall design intent does not change. This would need to be submitted as a Substitution Request. Engineered Drawings would not be required for the initial substitution request but would be required to be provided during the submittal phase.

ITEM #5: Vendor Drawings – The vendor drawings for the GE Imaging equipment have been included in the Addendum for reference.

ITEM #6: Fire Alarm Vendor Information – The hospital's vendor for Fire Alarm services is Vitel Communications. This Work identified for this project will need to be performed by this Contractor and included in submitted proposals.

ITEM #7: Security Contractor – The hospital's vendor for Security services, including access controls is IdeaComm. They will be providing the Tap Badge Readers (devices only, backbox and conduit to above ceiling by Contractor), cabling to Access Controls system, and tie-in to access controls system directly to the Owner under separate contract. Contractor shall coordinate with IdeaComm on schedule for install.

ITEM #8: Roofing Patch Back – Please note that the existing roof above this area is NOT TPO as indicated. The existing is a Mod Bit system with a coating over it (not to be matched). Patch back for roof curbs or penetrations shall be made using modified bitumen system materials and coated with Certainteed SmartCoat Silicone system using SmartCoat 200 Asphalt Bleed Blocker and SmartCoat 450 High Solids Silicone Coating to patch back into existing materials. Use other SmartCoat system components (primers, flashing adhesives, mastic, etc.) as necessary for a complete and proper installation.

ITEM #9: Revised Drawings – Refer to the attached, revised sheets CR2, A2, A3, A6 & A8. These sheets are to be incorporated into the Contract Documents and take the place of previously issued versions.

ITEM #10: Contractor Access and vehicle access – Refer to the attached drawings providing information on Contractor Access and vehicular access to deliver materials to the basement.

ITEM #11: Qualification Statement and Management Plan – As part of the Bid submission, Contractors shall provide a Qualification Statement, this could be an AIA A305 Document or some other proprietary information that provides similar information about the Company. Contractor shall also provide a Management Plan to include Project Manager and Superintendent and any assistants to these if applicable.

Refer to attached MPE Addendum Items.

End of Addendum

Pre-Bid Sign-In Sheet



	✓	NAME	COMPANY/DEPARTMENT	EMAIL ADDRESS:
1		DAVID WRIGHT	Kel-Tex Electric	DAVID@KELTEXELECTRIC.COM
2		John Asplof	Asplof Paint	asplofpaint@yahoo
3		JAMES SMITH SARAH DEEROD	INGRAM'S FLOORING	sarah@ingramsflooring.com
4	✓	DARIN HOLUBAK	WR CONSTRUCTION, INC.	DARIN@WRGENCONV-INC.COM
5		Fredy Allgood	CPDA	rollgoodcpda@gmail.com
6		Robert Chambers	CHAMBERS ELECTRIC	bob@chamberstelec.com
7		Roy Hernandez	R Plumbing LLC	rplumbingancon110@gmail.com
8		Sam Gorder	mmm Plumbing	sam@mmmpha.com
9		Juan Sosa	Sosa's Painting	paintingSosa@yahoo.com
10	✓	JERRY REYNOSA	TRI-STATE G.C.	jerry@tristategc.com
11	✓	CORY MATHIS	WESTERN BUILDERS	C.MATHIS@WBAMARILCO.COM
12		Nick Barksdale	Royal Arch Products	nick@rapltd.net

13		Eric Hergwood	Roys Unit	
14		Mike Sivik	Roys Unit	
15	✓	RAYMOND BOYNTON	PLANS BUILDERS	
16		Andy Aguirre	VF Fab	Andy.Aguirre@VFFabLLC.com
17		Cealia Ramirez	GMiranda	gmiranda3701@gmail.com
18		Heather Swafford	A1 FLAIRS	Hswafford@a1flairs.com
19		Jason Moseko	Panhandle Fire	jason@panhandlefire.com
20		Daniel Scott	Scottco	dscott@scottco.com
21		Cody Hodge	Cornerstone Electric	chodge@CSEama.com
22		DAVID NANCE	DENMAN BP	DAVID@DBROFFICE.COM
23	✓	John Baker	Southwest GC	johnb@swgc.net
24		SIMMIE CALLAHAN ✓	ERAC SERVICES	SIMMIE@ERACSERVICE.COM
25	✓	WES PURSTER	SOUTHWEST G.C., INC.	WES@swgc.net
26		Victoria Abadie	Verity Mechanical	Victoria@veritymechanical.com

27	✓	Kasey Baker	Tri-State General Contractors	kbaker@tristategc.com
28		Eric Henriksen Jr	Henriksen Concrete Contractors	ehenriksen91@gmail.com
29		Daniel Ross	Vitel Communications	danielr@vitelcommunications.com
30		Juan Crispin	Optimum Concrete	Juan.crispin99@Gmail.com
31		Jamie Lloyd	American Electric	jllloyd@americanelectricamarillo.com
32		Brian Mensen	American Electric	brian@americanelectricamarillo.com
33		Tim Benton	Shields	benton.timothy@gmail.com
34		Faron Walker	Ben-Hur Construction	Ben-Hur@Ben-Hur.com
35	✓	Tim Roth	Lott Brothers Construction	Bids@lottbrothers.com
36		Chen Shields	Shields Plumbing Services	shieldsplumbingservices@yahoo.com
37		Michael Christian	MMM	estimating@MMMPHA.com
38		Jason Steink	mmm	jason@mmmpa.com
39		Donny King	Pro-Air	donny@amarilloproair.com
40				



**BSA Health System
Amarillo, TX
United States of America**

A	12/Feb/2025	Final (DC-464580)
REV	DATE	MODIFICATIONS

01 - C1 - Cover Sheet	16 - E1 - Electrical Notes
02 - C2 - Disclaimer - Site Readiness	17 - E2 - Electrical Layout
03 - A1 - General Notes	18 - E3 - Electrical Elevations
04 - A2 - Equipment Layout	19 - E4 - Power Requirements
05 - A3 - Radiation Protection	20 - E5 - Details - Interconnections
06 - A4 - Radiation Protection Details	
07 - A5 - Equipment Dimensions (1)	
08 - A6 - Equipment Dimensions (2)	
09 - A5 - Delivery	
10 - S1 - Structural Notes	
11 - S2 - Structural Layout	
12 - S3 - Structural Details (1)	
13 - S4 - Structural Details (2)	
14 - S5 - Structural Details (3)	
15 - M1 - HVAC	



Katrina Schoepf
682-249-7024
Katrina.schoepf@gehealthcare.com

**OMNI LEGEND
FINAL STUDY**

A mandatory component of this drawing set is the GE HealthCare Pre Installation manual. Failure to reference the Pre Installation manual will result in incomplete documentation required for site design and preparation.
Pre Installation documents for GE HealthCare products can be accessed on the web at: <https://www.gehealthcare.com/support/manuals>

GE HealthCare does not take responsibility for any damages resulting from changes on drawings made by others. Errors may occur by not referring to the complete set of final issue drawings. GE HealthCare cannot accept responsibility for any damage due to the partial use of GE HealthCare final issue drawings, however caused. All dimensions are in millimeters unless otherwise specified. Do not scale from printed pdf files. GE HealthCare accepts no responsibility or liability for defective work due to scaling from these drawings.

Drawn by	Verified by	Concession	GON/Quote	PIM Manual	Rev
KGK	CRM	-	2007601759.16	5881677-1EN	5
Format	Scale	File Name		Date	Sheet
A3	1/4"=1'-0"	PET-M417959-FIN-00-A.DWG		12/Feb/2025	01/20

DISCLAIMER

GENERAL SPECIFICATIONS

- GE is not responsible for the installation of developers and associated equipment, lighting, cassette trays and protective screens or derivatives not mentioned in the order.
- The final study contains recommendations for the location of GE equipment and associated devices, electrical wiring and room arrangements. When preparing the study, every effort has been made to consider every aspect of the actual equipment expected to be installed.
- The layout of the equipment offered by GE, the dimensions given for the premises, the details provided for the pre-installation work and electrical power supply are given according to the information noted during on-site study and the wishes expressed by the customer.
- The room dimensions used to create the equipment layout may originate from a previous layout and may not be accurate as they may not have been verified on site. GE cannot take any responsibility for errors due to lack of information.
- Dimensions apply to finished surfaces of the room.
- Actual configuration may differ from options presented in some typical views or tables.
- If this set of final drawings has been approved by the customer, any subsequent modification of the site must be subject to further investigation by GE about the feasibility of installing the equipment. Any reservations must be noted.
- The equipment layout indicates the placement and interconnection of the indicated equipment components. There may be local requirements that could impact the placement of these components. It remains the customer's responsibility to ensure that the site and final equipment placement complies with all applicable local requirements.
- All work required to install GE equipment must be carried out in compliance with the building regulations and the safety standards of legal force in the country concerned.
- These drawings are not to be used for actual construction purposes. The company cannot take responsibility for any damage resulting therefrom.

CUSTOMER RESPONSIBILITIES

- It is the responsibility of the customer to prepare the site in accordance with the specifications stated in the final study. A detailed site readiness checklist is provided by GE. It is the responsibility of the customer to ensure all requirements are fulfilled and that the site conforms to all specifications defined in the checklist and final study. The GE Project Manager of Installation (PMI) will work in cooperation with the customer to follow up and ensure that actions in the checklist are complete, and if necessary, will aid in the rescheduling of the delivery and installation date.
- Prior to installation, a structural engineer of record must ensure that the floor and ceiling is designed in such a way that the loads of the installed system can be securely borne and transferred. The layout of additional structural elements, dimensioning and the selection of appropriate installation methods are the sole responsibility of the structural engineer. Execution of load bearing structures supporting equipment on the ceiling, floor or walls are the customer's responsibility.

RADIO-PROTECTION

- Suitable radiological protection must be determined by a qualified radiological physicist in conformation with local regulations. GE does not take responsibility for the specification or provision of radio-protection.

THE UNDERSIGNED, HEREBY CERTIFIES THAT I HAVE READ AND APPROVED THE PLANS IN THIS DOCUMENT.		
DATE	NAME	SIGNATURE

CUSTOMER SITE READINESS REQUIREMENTS

REQUIRED MANUALS FOR SYSTEM PRE-INSTALLATION	
Description	Document Number*
Product specific Pre-installation Manual	Refer to cover page
*documents can be accessed in multiple languages at https://www.gehealthcare.com/support/manuals	

- A mandatory component of this drawing set is the GE HealthCare Pre-installation manual. Failure to reference the Pre-installation manual will result in incomplete documentation required for site design and preparation.
- The items on the GE HealthCare Site Readiness Checklist **DOC2949061** and Worksheet **DOC2949068** are **REQUIRED** to facilitate equipment delivery to the site. Equipment will not be delivered if these requirements are not satisfied.
 - Any deviation from these drawings must be communicated in writing to and reviewed by your local GE HealthCare installation project manager prior to making changes.
 - Make arrangements for any rigging, special handling, or facility modifications that must be made to deliver the equipment to the installation site. If desired, your local GE HealthCare installation project manager can supply a reference list of rigging contractors.
 - New construction requires the following;
 1. Secure area for equipment,
 2. Power for drills and other test equipment,
 3. Restrooms.
 - Provide for refuse removal and disposal (e.g. crates, cartons, packing)
 - It is required to minimize vibrations within the scan room. It is the customer's responsibility to contract a vibration consultant/engineer to implement site design modifications to meet the GE vibration specification. Refer to the system Pre-installation manual for vibration specifications.

ENVIRONMENT

ALTITUDE

- Operating altitude: from -150 m [-492 ft] (below) to 3000 m [9843 ft] (above) sea level.

MAGNETIC FIELD SPECIFICATIONS

- Limit the magnetic interference to guarantee specified imaging performance.

GANTRY

- Ambient static magnetic fields less than 1 Gauss.
- Ambient AC magnetic fields less than 0.01 Gauss.

OPERATOR CONSOLE, PARC4.X and Computer Equipment

- Ambient static magnetic fields less than 10 Gauss.

SYSTEM COMPONENT NOISE LEVEL

- **Maximum Gantry Audible Noise Level:** The maximum ambient noise level is produced by the gantry during a CT scan acquisition. It is less than 68 dBA when measured at a distance of 1 m [3.3 ft] from the nearest gantry surface in any direction.
- **Maximum Console Audible Noise Level:** The maximum ambient noise levels is less than or equal to 54 dBA when measured at a distance of 1 m [3.3 ft] from nearest console surface in any direction.

BACKGROUND RADIATION


- It is important that background radiation be kept to a minimum. The coincidence detection used in a PET system allows a moderate amount of external singles events. The PET/CT system has been found to have less than 1% deadtime if the external field is below 1 mR/hr from a single source.
- Because area background can be more general than a single source, a lower limit is appropriate. If the area dose rate is maintained to less than 0.2 mR/hr (due to 511 or lower energy gamma rays) at the covers, detector deadtime should not exceed 1%.
- Radioactive sources must be stored in approved shielded containers or be stored in a separate room (hot lab) adjacent to, and accessible from, the Scan Room. This hot lab should be near the cyclotron (if used). Doses should be prepared in the same area.

VIBRATION SPECIFICATIONS

- Shock Restrictions: The system cannot tolerate shock or vibration. System components cannot be tipped, dropped, or hoisted.
- The scanning facility shall be isolated from vibration such as; hospital power plants, pumps, motors, air handling equipment, air conditioning units, nearby rooms with exercise equipment or where exercise occurs, hallway foot traffic, elevators, parking lots, roads, subways, trains, and heliports; otherwise, vibration will affect the image quality of the scanner.
- PET/CT systems are sensitive to vibration and may display limited performance if exceeding the vibration limits listed below. The band of frequencies in which systems exhibit the most sensitivity appears at or near the resonant frequencies of the gantry and the patient table, the latter of which varies depending on patient mass and location. These frequencies fall within the following ranges:
 - Patient Table: 2 – 10 Hz
 - Gantry: 8 – 14 Hz
- It is the customer's responsibility to contract a vibration consultant or qualified engineer to verify that these specifications are met and implement an appropriate solution.

IMPORTANT CUSTOMER READINESS ALERT

- This equipment involves the use of radioactive isotopes, including those sources necessary for equipment calibration. Appropriate regulatory compliance and licensing must be arranged by the customer early in the planning process and then demonstrated/available for equipment installation.
- Note: delivery path down corridors for gantry's and table must be evaluated prior to construction, as 90 degree turns require specific corridor width.



LEGEND

A	GE SUPPLIED	D	AVAILABLE FROM GE
B	GE SUPPLIED/CONTRACTOR INSTALLED	E	EQUIPMENT EXISTING IN ROOM
C	CUSTOMER/CONTRACTOR SUPPLIED AND INSTALLED	*	ITEM TO BE REINSTALLED FROM ANOTHER SITE


BY	ITEM	DESCRIPTION	MAX HEAT OUTPUT (BTU/h)	WEIGHT (lbs)	MAX HEAT OUTPUT (W)	WEIGHT (kg)
A	1	GANTRY	21257	6192	6230	2808
A	2	PATIENT TABLE	1024	1813	300	822
A	3	AUTO PATIENT POSITIONING DEPTH CAMERA	-	7	-	3.2
A	4	AVIMOS CAMERA	-	-	-	-
A	5	CCTV CAMERA	-	-	-	-
A	6	INJECTOR ON CEILING	-	79	-	36
A	7	ANNULUS PHANTOM SHIELD CONTAINER	-	309	-	140
A	8	IVY 7800 CARDIAC TRIGGER MONITOR	-	19	-	8.54
A	9	POWER DISTRIBUTION UNIT (PDU)	9724	816	2850	370
A	10	PARTIAL UPS 14.4 KVA	5122	609	1501.1	276
A	11	CHILLER PDB	-	66	-	30
B	12	MAIN DISCONNECT PANEL (MDP)	-	46	-	21
A	13	RECONSTRUCTION MINI CABINET (PARC4.X)	12966	497	3800	225.2
A	14	AIRSYS CHILLER	9724	485	2850	220
A	15	RCK-AVIMOS CONSOLE	-	-	-	-
A	16	CONSOLE MONITORS	-	14	-	6.4
A	17	OPEN CONSOLE	3207	142	940	64.5
A	18	INJECTOR CONTROL	-	-	-	-
A	19	CCTV MONITOR	-	8	-	3.5
A	20	OPERATOR'S CHAIR	-	-	-	-
A	21	GE STORAGE CABINET	-	150	-	68
C	22	COUNTER TOP FOR EQUIPMENT- PROVIDE GROMMETED OPENINGS AS REQUIRED TO ROUTE CABLES				
C	23	CONTROL WALL TO CEILING WITH LEAD GLASS VIEWING WINDOW				
C	24	MINIMUM OPENING FOR EQUIPMENT DELIVERY IS 1067 mm x 2032 mm [42 in x 80 in],				

EXAM ROOM HEIGHT

FINISHED FLOOR TO SLAB HEIGHT	11'-0"
FALSE CEILING HEIGHT	9'-0"

For Accessory Sales: (866) 281-7545 Options 1, 2, 1, 2 or mail to: gehccaccessorysales@ge.com

RADIATION PROTECTION LAYOUT



SHIELDING REQUIREMENTS SCALING

CHANGED PARAMETER (mAs)	MULTIPLICATION FACTOR (new mAs/100)
80 kV	0.24
100 kV	0.45
120 kV	0.71
140 kV	1.00
1 mm aperture	0.20
3 mm aperture	0.22
5 mm aperture	0.27
10 mm aperture	0.38
15 mm aperture	0.48
20 mm aperture	0.59
30 mm aperture	0.79
40 mm aperture	1.00

SHIELDING REQUIREMENTS:

Engage a qualified radiological health physicist to review your scan room shielding requirements, taking into consideration:

- Scatter radiation levels within the scanning room
- Equipment placement.
- Weekly projected work-loads (number of patients/day technique (kvp*ma))
- Materials used for construction of walls, floors, ceiling, doors, and windows.
- Activities in surrounding scan room areas.
- Equipment in surrounding scan room areas (e.g., film developer, film storage)
- Room size and equipment placement within the room relative to room size.

The illustrations on this page depict measured radiation levels within the scanning room, while scanning a 32 cm CTDI phantom with the technique shown:

- 140 kV
- 100 mA
- 1 sec
- 40 mm



Use the mAs, kV and aperture scaling factors in the table shown here to adjust exposure levels to the scan technique used at the site.

NOTE: Actual measurements can vary. Expected deviations equals $\pm 15\%$, expect for the 5 mA and 1 mm techniques, where variations may be greater (up to a factor of 2), due to the inherent deviation in small values. The maximum deviation anticipated for tube output equals $\pm 40\%$.

RADIATION SCATTER - BODY PHANTOM

NOTE: 140 kV
100 mAs/scan
1 sec
40mm aperture

The iso-countour dose levels are in $\mu\text{Gy}/\text{sec}$ (micrograys/sec) to measure radiation levels. The conversion factor from mR to μGy (micrograys) is: $1 \text{ mR} = 8.69 \mu\text{Gy}$.



DETAIL NOT TO SCALE

RADIOACTIVE ISOTOPES

RADIOACTIVE ISOTOPES AND RADIOPROTECTION

Since the system produces X-ray radiation and involves the use of radioactive isotopes, compliance with Nuclear Regulatory Commission regulations (or country similar regulatory requirements), must be adhered to and all permissions obtained well in advance.

It is Customer's responsibility consult a qualified radiological health physicist for radiation protection requirements for the walls, floor, ceiling, doors, window glass, etc.(lead content and thickness) and warning lights and signs, in accordance with local requirements.


It is essential that regulatory compliance and preparations are completed early so that required source materials can be obtained prior to installation, including calibration sources and isotopes. These sources and isotopes may have fairly long delivery lead times and a short half-life, so that it may not be advisable to store them over long periods of time.

RADIOACTIVE SOURCE - ISOTOPE


The PET/CT system uses the following radioactive sources during calibration and the Daily QA Check.

Daily QA Check (Annulus phantom)	Isotope	Germanium-68
	Activity level	55 MBq \pm 20%
Check Image Alignment procedure (VQC phantom)	Isotope	Germanium-68
	Activity level	3.5 MBq
Typical Positron Emitting Isotopes include	Fluorine 18	
	Carbon 11	
	Nitrogen 13	
	Oxygen 15	
It is the customer's responsibility provide isotopes for system calibration and prepare the required doses.		

GANTRY WITH PATIENT TABLE




POWER DISTRIBUTION UNIT (PDU)




CUSTOMER SUPPLIED WORKSPACE AND OPERATOR CONSOLE

CUSTOMER SUPPLIED TABLE




CONSOLE DIMENSIONS




SCALE 1:20

UNINTERRUPTIBLE POWER SUPPLY


TOP VIEW



FRONT VIEW




SIDE VIEW




SCALE 1:20

Center of Gravity


PARC4.X RECONSTRUCTION MINI CABINET




CHILLER



CHILLER PDB



MAIN DISCONNECT PANEL



DELIVERY

THE CUSTOMER/CONTRACTOR SHOULD:

- Provide an area adjacent to the installation site for delivery and unloading of the GE equipment.
- Ensure that the dimensions of all doors, corridors, ceiling heights are sufficient to accommodate the movement of GE equipment from the delivery area into the definitive installation room.
- Ensure that access routes for equipment will accommodate the weights of the equipment and any transportation, lifting and rigging equipment.
- Ensure that all necessary arrangements for stopping and unloading on public or private property not belonging to the customer have been made.


DIMENSIONS OF DELIVERY WITH DOLLY TRANSPORT EQUIPMENT

Below dimensions shown with side rails on. The minimum unobstructed hallway width is 1803 mm [71 in], the minimum clear doorway openings is 1067 mm [42 in] to accommodate delivery of the system.


EQUIPMENT	DIMENSIONS		WEIGHT	
PATIENT TABLE (Blue dollies)	LENGTH	3836 mm 151 in	1165 kg	2568 lbs
	WIDTH	864 mm 34 in		
	HEIGHT	1410 mm 55.5 in		
CT GANTRY	LENGTH	2775 mm 109 in	1835 kg	4045 lbs
	WIDTH	1291 mm 51 in		
	HEIGHT	2000 mm 79 in		
PET IMAGE RING	LENGTH	2775 mm 109 in	1490 kg	3285 lbs
	WIDTH	926 mm 36.5 in		
	HEIGHT	1713 mm 67.4 in		

SHIPPING DOLLY DIMENSIONS FOR GANTRY

CT GANTRY



PET IMAGE RING




Weight with dollies and side rails = 1835 kg [4049 lbs]

Weight with dollies = 1490 kg [3285 lbs]

STRUCTURAL NOTES


- Methods of support for the steelwork that will permit attachment to structural steel or through bolts in concrete construction should be favored. Do not use concrete or masonry anchors in direct tension.
- All units that are wall mounted or wall supported are to be provided with supports where necessary. Wall supports are to be supplied and installed by the customer or his contractors. See plan and detail sheets for suggested locations and mounting hole locations.
- All ceiling mounted fixtures, air vents, sprinklers, etc. To be flush mounted, or shall not extend more than 6,35mm (1/4") below the finished ceiling.
- Floor slabs on which equipment is to be installed must be level to 6.00mm (1/4") in 3050mm (10'-0")
- Dimensions are to finished surfaces of room.
- Customers contractor must provide all penetrations in post tension floors.
- Customers contractor must provide and install any non-standard anchoring. Documents for standard anchoring methods are included with GE equipment drawings for geographic areas that require such documentation.
- Customers contractor must provide and install hardware for "through the floor" anchoring and/or any bracing under access floors. This contractor must also provide floor drilling that cannot be completed because of an obstruction encountered while drilling by the GE installer such as rebar etc.
- It is the customer's responsibility to perform any floor or wall penetrations that may be required. The customer is also responsible for ensuring that no subsurface utilities (e.g., electrical or any other form of wiring, conduits, piping, duct work or structural supports (i.e. post tension cables or rebar)) will interfere or come in contact with subsurface penetration operations (e.g. drilling and installation of anchors/screws) performed during the installation process. To ensure worker safety, GE installers will perform surface penetration operations only after the customer's validation and completion of the "GE surface penetration permit"



ITEM	DESCRIPTION
(CONTRACTOR SUPPLIED & INSTALLED)	
1	Floor contact area for gantry and patient table. See Structural Details.
2	Floor penetrations not allowed in temporary service rail area.
3	Support Backing, locate as shown
4	Unistrut or equivalent for mounting patient positioning camera mounting plate on ceiling. Support designed and supplied by customer. Supports to be at least 2' [610mm] in length and located per dimensions on Positioning Camera Mounting Plate structural detail.
5	Structural supports for fastening the overhead counterpoised suspension. Support should run continuous with no fittings extending below face of channel, be parallel, square, and in the same horizontal plane, above finished ceiling. Ensure mounting surface is installed level or plumb within +/- 1 degree, and is structurally sufficient to maintain a level or plumb condition under 110 lb (50kg) system load and maximum system moment of 4400 in-lb (500n-m). Methods of support that will permit attachment to structural steel or through bolts in concrete construction should be favored. Do not use screw anchors in direct tension. 14" x 14" x 1/2" thick steel plate provided by manufacturer. See detail on structural detail sheets.
6	RCK-AVIMOS Camera Mount locate as shown. See Structural Detail
Camera Position Note: Position of camera(s) must be calculated and verified by GEHC PMI or Field Engineer for final location accuracy.	
Dimension Precision Note: Metric dimensions should be referenced when positioning the CT gantry alignment tool.	

ANCHORING/LOADING DISTRIBUTION TO THE FLOOR


ANCHORING AND FLOOR REQUIREMENTS



- (1) PET primary scan plane axis
- (2) CT scan plane axis
- (3) Longitudinal axis
- (4) Cable access
- (5) Hose access
- (6) Secondary cable and hose access
- (7) 8 anchoring points for the Table
- (8) 16 anchoring points for the Gantry
- (9) 8 detachable rail leveling pads used only during service
- (10) 3 adjuster/leveling pads
- (11) 2 table calibration brackets
- Main anchoring points
- Backup anchoring points

SCALE 1:25

GE SUPPLIED GANTRY ANCHORS (5867778)



FINISHED FLOOR REQUIREMENTS


- Installation requires a finished floor in the scan and control rooms.
- The floor surface in the scan room directly under the gantry and table must be level.
- The floor shall be no greater than 6 mm [0.25 in] out of level over a 3048 mm [10 ft] range, with level defined as the horizontal surface between the highest and lowest points.
- The floor shall have a minimum concrete thickness of 102 mm [4 in].
- Shims should not be used to compensate for a floor that does not meet this requirement.
- These requirements apply to all installation types.

NOT TO SCALE

NOTES:

If the concrete floor has a floor covering installed over it (such as floor tile), 17 openings 101.6 mm [4 in] in diameter will be cut into the floor covering to ensure the table and gantry rest on the concrete. (Openings are cut during installation.)

POSITIONING CAMERA MOUNTING PLATE



GE will provide a Junction Plate, shipped with the system. If the Junction Plate supplied by GE can not meet the requests of the customer or the building structure, the customer's architect can design and install the Junction Plate (refer to the right side of the detail) with sufficient strength to hold the camera assembly.

Material: Steel material with a min. tensile strength of 375 MPa
Plate thickness: 2.5 mm [0.10 in]


Welding Nut: Meet GB-T 13681-1992 requirement or equivalent		
	M5-0.8 mm	M6-1.0 mm
Thickness (mm [in])	3.7-4 [0.15-0.16]	4.7-5 [0.19-0.20]
Pledge load (N)	11000	15500

NOTE: The system manufacturer will NOT inspect and test that the fixing methods between the Junction Plate and the building structure meet the loading capacity specified (recommend a 6x safety factor), which is the customer's responsibility. The weight of the camera assembly is approximately 3.2 kg [7.05 lbs], suggest the safety load on the Junction Plate is no less than 20 kg [44.09 lbs]. If the Anchor Bolt is not applicable for site requirement, the customer's architect can consider other methods (such as welding...) to fix the Junction Plate. Presetting for site preparation of the Camera installation, customer had better install the Junction Plate in advance before the system installation.

NOT TO SCALE


AVIMOS MOUNTING PLATES

STANDARD JUNCTION PLATE SUPPLIED BY GE



If a structural contractor designed an equivalent flat plate, the thickness should be 15 mm [0.59 in] or more, three (3) M4 mounting holes are required to anchor the camera bracket to the junction plate and one (1) M5 hole is used to anchor the safety chain. Please consider the loading capacity of the junction plate, the total weight of the camera and bracket provided by GE is 0.34 kg [0.74 lbs].

JUNCTION PLATE FOR PIPE SUPPLIED BY GE




If a structural contractor designed an equivalent flat plate, the thickness should be 15 mm [0.59 in] or more, four (4) M6 mounting holes are required to anchor the camera bracket to the junction plate and one (1) M5 hole is used to anchor the safety chain. Please consider the loading capacity of the junction plate, the total weight of the camera and extendable pipe provided by GE is 0.67 kg [1.47 lbs].

Welding Nut: Meet GB-T 13681-1992 requirement or equivalent		
	M5	M6
Thickness (mm [in])	3.7-4 [0.15-0.16]	4.7-5 [0.19-0.20]
Pledge load (N)	11000	15500

NOTE: GE will provide two junction plates (Standard and Pipe). If the junction plates supplied by GE can not meet the requests of the building structure, the customer's architect can design and install the equivalent junction plate with sufficient strength to hold the camera. The customer's architect is responsible for installing of junction plate. The system manufacturer will NOT inspect and test that the fixing methods between the Junction Plate and the building structure meet the loading capacity specified (recommend a 4x safety factor).

NOT TO SCALE


POSITIONING CAMERA INSTALLATION POSITION



NOT TO SCALE

AVIMOS INSTALLATION POSITION


STANDARD CONFIGURATION



The junction plates installed on the wall structural is the customer's responsibility, so the junction plate must be installed by customer in advance, and then field engineer installs camera.

Center of Gravity
NOT TO SCALE


PIPE CONFIGURATION



The junction plates are installed on the ceiling structural is the customer's responsibility, so the junction plate must be installed by customer in advance, and then field engineer installs camera.

The extendable pipe B-cat must be purchased in advance after PMI checked room size and layout. There are two extendable pipe B-cats for selection, one is for ceiling mount 40-60 cm [15.74-23.62 in], the other is for ceiling mount 85-150 cm [33.46-59.06 in].

CUSTOMER/CONTRACTOR SUPPLIED MOUNTING PLATE



The exact location of all five drill holes for MAVIG column has to be kept, otherwise installation can't be accomplished. Column flange and safety chain fixings to concrete or to structure other than MAVIG anchoring plate or MAVIG bridge shall be defined by a structural company. All design and pre-installation activity must be done in accordance of the MAVIG Installation manual. Contact your GE Project Manager for OEM documentation. Installation of mounting plate performed by GE or a GE sub-contractor.

NOT TO SCALE

CEILING SUSPENSION DISCLAIMER

Safety and precautionary comments:

Only qualified, licensed technicians can perform electrical connections, installation, removal and repair. It is strongly recommended that at least two persons perform the installation.

Installing the system: Prior to installation, a structural engineer must confirm that the mounting structure is strong enough to provide proper support for the entire system and any attached end devices. Installation must be completed according to local building codes.

Determination of required installation hardware and torque values for installation of the ceiling column and ceiling track is the sole responsibility of the structural engineer.

Ceiling mounted systems must be installed properly. Failure to follow the instructions provided may lead to a potentially dangerous and unstable condition of the system.

GE and/or MAVIG is not responsible for unauthorized modifications made to the system or use of the system for unintended purposes. GE and/or MAVIG cannot be held liable for improper operation and modifications. Since improper modifications may impair proper operation, safety or reliability of the system, product modifications require written authorization from MAVIG.


Under GE responsibility or under Customer responsibility, for all pre-installations, whatever is the supporting structure (bridge, chair, Unistrut channel, other channels, direct anchorage in concrete, transversal beam, etc. ...) a certificate must be obtained from a structural engineer.

This certificate shall include the definition of fasteners and of their tightening torque, especially for the non-standard cases described in MAVIG PIM and for which the standard anchoring/screws delivered with product shall not be used but shall be defined (and implemented in most cases) by the structural company.

WARNING:

It is prohibited to alter the length of the ceiling column or remove any securing screws.


SUSPENSION COLUMN LENGTHS AND INSTALLATION DETAILS



- Available column lengths might differ, please refer to the GE commercial catalog for current selection options
- For rooms with higher mounting point than 3200 mm [126 in], a ceiling construction between structural ceiling and vertical column is suggested which needs to be designed by a structural engineer
- All design and pre-installation activity must be done in accordance of the MAVIG Installation manual
- Contact your GE Project Manager for OEM documentation
- Installation of mounting plate performed by GE or a GE sub-contractor

NOT TO SCALE

PORTEGRA2 COLUMN ASSEMBLY



- Safety chain shall be always attached.
- Do not use shims between column and mounting surface.

All design and pre-installation activity must be done in accordance of the MAVIG Installation manual. Contact your GE Project Manager for OEM documentation. Installation of mounting plate performed by GE or a GE sub-contractor.

NOT TO SCALE

TEMPERATURE AND HUMIDITY SPECIFICATIONS

IN-USE CONDITIONS

	Min	Recommended	Max
Temperature (up to 2400 m [7874 ft])	18°C	22°C	26°C
	64°F	72°F	79°F
Temperature (up to 3000 m [9842 ft])	18°C	22°C	25°C
	64°F	72°F	77°F
Temperature (up to 4000 m [13123 ft])	18°C	22°C	23°C
	64°F	72°F	73.4°F
Temperature gradient	≤ 3°C/h		
	≤ 5.4°F/h		
Relative humidity (1)	30% to 60%		
Humidity gradient	≤ 5%/h		

STORAGE CONDITIONS

Temperature	0°C to +30°C	+32°F to +86°F
Relative humidity (1)	≤ 70% RH	
Temperature gradient	≤ 3°C/h	≤ 5.4°F/h
Humidity gradient	≤ 5%/h	

Material should not be stored for more than 6 month.

(1) Non-condensing

AIR RENEWAL

According to local standards. The HVAC system should be designed to provide 5 air changes per hour to maintain adequate air quality and temperature.

NOTE : In case of using air conditioning systems that have a risk of water leakage it is recommended not to install it above electric equipment or to take measures to protect the equipment from dropping water.

HEAT DISSIPATION

ROOM	DESCRIPTION	HEAT DISSIPATION (kW)	HEAT DISSIPATION (BTU/hr)
		MAX	MAX
Exam Room	PET Gantry	0.73	2500
	CT Gantry	5.50	18700
	Patient table	0.30	1050
	TOTAL	7	22250
Exam room or Technical room*	Power Distribution Unit (CT PDU)	2.85	9700
	PARC 4.X (Reconstruction Mini Cabinet)	3.80	13000
	CT Partial UPS	1.5	5122
	Chiller	2.85	9700
	TOTAL	11	37522
Control Room or Reporting Room	Standalone Console	0.84	2860
	LCD Monitor (2 units, 170 BTU/50 Watts each)	0.10	340
	TOTAL	1	3200

*Technical Room is not mandatory, the placements of these elements are recommended in the Exam Room.

WARNING This chart contains only the principal components of the PET/CT system and does not include information about non-GE supplied equipment.

CONNECTIVITY REQUIREMENTS

Your new GE Healthcare imaging modality will require local and remote connectivity to enable our full range of digital support:

- Local connectivity - This allows your system to connect to local devices such as PACS and modality worklist. We will require network information to configure the system(s), and a live ethernet port(s) prior to the delivery of the system(s).
- Remote connectivity - Your GE Healthcare service warranty includes InSite™ (applicable to InSite capable products), a powerful broadband-based service which enables digital tools that can help guard your hospital against equipment downtime and revenue loss by quickly connecting you to a GE Healthcare expert.

Depending on product family and software version, imaging systems can be connected in one of the following methods:


1. TLS over TCP Port 443 (Preferred method for new products) via:
 - a. DNS resolution
 - b. Customer-provided Proxy or
 - c. GE Proxy (Available in some regions)
2. Site-to-Site IPsec VPN tunnel

Please provide the GE project manager with the contact information for the resource that can provide information required to set up these connections. GEHC will send out communication to these contacts, which will include the project's Connectivity requirements, and a Connectivity form. This form will need to be completed and returned to GEHC prior to delivery of the system to ensure the system is tested and connectivity is enabled prior to the completion of the installation.

ELECTRICAL NOTES

1. Aluminum or solid wires are not allowed.
2. Wire sizes given are for use of equipment. Larger sizes may be required by local codes.
3. It is recommended that all wires be color coded, as required in accordance with national and local electrical codes.
4. Conduit sizes shall be verified by the architect, electrical engineer or contractor, in accordance with local or national codes.
5. Convenience outlets are not illustrated. Their number and location are to be specified by others. Locate at least one convenience outlet close to the system control, the power distribution unit and one on each wall of the procedure room. Use hospital approved outlet or equivalent.
6. General room illumination is not illustrated. Caution should be taken to avoid excessive heat from overhead spotlights. Damage can occur to ceiling mounting components and wiring if high wattage bulbs are used. Recommend low wattage bulbs no higher than 75 watts and use dimmer controls (except MR). Do not mount lights directly above areas where ceiling mounted accessories will be parked.
7. Routing of cable ductwork, conduits, etc., must run direct as possible otherwise may result in the need for greater than standard cable lengths (refer to the interconnection diagram for maximum usable lengths point to point).
8. Conduit turns to have large, sweeping bends with minimum radius in accordance with national and local electrical codes.
9. In some cases GEHC will specify ground wires to be sized larger than code. In these situations, the GEHC specification must be followed.
10. A special grounding system is required in all procedure rooms by some national and local codes. It is recommended in areas where patients might be examined or treated under present, future, or emergency conditions. Consult the governing electrical code and confer with appropriate customer administrative personnel to determine the areas requiring this type of grounding system.
11. The maximum point to point distances illustrated on this drawing must not be exceeded.
12. Physical connection of primary power to GEHC equipment is to be made by customers electrical contractor with the supervision of a GEHC representative. The GEHC representative would be required to identify the physical connection location, and insure proper handling of GEHC equipment.
13. GEHC conducts power audits to verify quality of power being delivered to the system. The customer's electrical contractor is required to be available to support this activity.
14. Every installation is unique. The electrical contractor will be required to support the installation of the GEHC equipment by providing knockouts, grommeted openings, bushings, etc. as required. All power connections to be performed by the electrician.


- All junction boxes, conduit, duct, duct dividers, switches, circuit breakers, cable tray, etc., are to be supplied and installed by customers electrical contractor. All junction boxes shall be provided with covers.
- Conduit and duct runs shall have gradual sweep radius bends.
- Conduits and duct above ceiling or below finished floor must be installed as near to ceiling or floor as possible to reduce run length.
- Ceiling mounted junction boxes illustrated on this plan must be installed flush with finished ceiling.
- All ductwork must meet the following requirements:
 1. Ductwork shall be metal with dividers and have removable, accessible covers.
 2. Ductwork shall be certified/rated for electrical power purposes.
 3. Ductwork shall be electrically and mechanically bonded together in an approved manner.
 4. PVC as a substitute must be used in accordance with all local and national codes.
- All openings in raceway and access flooring are to be cut out and finished off with grommet material by the customers contractor.
- Electrical contractor to provide measured pull strings in all conduit and raceway runs.
- Provide 10 foot pigtails at all junction points.
- Grounding is critical to equipment function and patient safety. Site must conform to wiring specifications shown on this plan.




Item	Electrical Layout Item List
1	Main disconnect panel (MDP)
2	Suitable bushings & lock nuts (Gantry)
3	Suitable bushings & lock nuts (Operator's Console)
4	Grommeted opening (PARC)
5	Suitable bushings & lock nuts / grommeted opening (Chiller)
6	4" x 4" x 4" [100 x 100 x 100] box (Partial UPS)
7	18" x 6" [450 x 150] surface wall duct with minimum 2 dividers
8	Grommeted opening / Suitable bushings & lock nuts (Power Distribution Unit)
9	3" [75] conduit below floor for water lines
10	2 1/2" [64] conduit below floor
11	3 1/2" [89] conduit below floor
12	Grommeted opening (Chiller PDB)
13	Cable inlet above ceiling (Express Camera)
14	6" x 6" x 4" [150 x 150 x 100] box above ceiling (injector)
15	6" x 6" x 4" [150 x 150 x 100] box (Operator's Console - Injector Control/Express Camera)
16	4" x 4" x 4" [100 x 100 x 100] box (CCTV Camera), TYP 7'-0" AFF to cl of box, final location per customer
17	4" x 4" x 4" [100 x 100 x 100] box (CCTV Monitor), TYP 4'-0" AFF to cl of box, final location per customer
18	4" x 4" x 4" [100 x 100 x 100] box (RCK-AVIMOS Camera), 6" TYP below finished clg to cl of box
19	6" x 6" x 4" [150 x 150 x 100] box (RCK-AVIMOS Console)
20	18" x 3 1/2" [450 x 100] surface wall duct with minimum 2 dividers
21	10" x 3 1/2" [250 x 100] surface wall duct with minimum 2 dividers

ITEM	QTY	Electrical Outlet Legend
Customer/contractor supplied and installed items unless otherwise specified. Height above floor determined by local codes unless otherwise specified.		
△		Dedicated telephone line(s)
▲		Network outlet
⊕		Duplex hospital grade, dedicated wall outlet 120-v, single phase power
⏻		System emergency off (SEO), (recommended height 1.2m [48"] above floor)
⊗		X-Ray room warning light control panel
⊙		X-Ray ON lamp (L1) - 24V
◇		Door interlock switch (needed only if required by state/local codes)


Additional Conduit Runs (Contractor Supplied and Installed)					
From (Bubble # / Item)	To (Bubble # / Item)	Qty	Size		
			In.	mm	
3 Phase Power	1 Main Disconnect Panel	1	As req'd	As req'd	
1 Main Disconnect Panel	Emergency Off	1	1/2	13	
	7 Power Distribution Unit	1	As req'd	As req'd	
7 Power Distribution Unit	Door Switch	1	1/2	13	
	Warning Light	Warning Light Control	1	1/2	13
1			1/2	13	
1 Phase Power		1	1/2	13	
13 Express Camera	15 Operator's Console	1	1 1/2	38	
1 Main Disconnect Panel	6 Partial UPS	1	1 1/4	30	
7 Power Distribution Unit		1	2	50	
14 Injector	15 Injector Control	1	2 1/2	64	
17 CCTV Monitor	16 CCTV Camera	1	1	25	
19 RCK-AVIMOS Console	18 RCK-AVIMOS Camera (x3)	1	1	25	




A



B



C



D

POWER REQUIREMENTS

POWER SUPPLY

POWER SUPPLY	3 PHASES+G 380V/400V/420V/440V/460V/480V ±10%
FREQUENCIES	50/60Hz ± 3Hz
POWER FACTOR	0.85
MAXIMUM POWER DEMAND	100 kVA
AVERAGE POWER	30 kVA

- Power supply should come into a Main Disconnect Panel (MDP) containing the protective units and controls.
- Governing electrical codes may require a neutral wire. If present, neutral must be terminated in MDP.
- The section of the supply cable should be calculated in accordance with its length and the maximum permissible voltage drops, equal to 3.4% max. of regulation for feeder size.
- There must be discrimination between supply cable protective material at the beginning of the installation (main low-voltage transformer side) and the protective devices in the MDP.
- TNC neutral point connection must not be used.
- Potential future upgrade may require a Maximum Power Demand of up to 140 kVA to be compatible.

SUPPLY CHARACTERISTICS

- Power input must be separate from any others which may generate transients (elevators, air conditioning, radiology rooms equipped with high speed film changers...).
- All equipment (lighting, power outlets, etc...) installed with GE system components must be powered separately.
- The minimum recommended size for a dedicated distribution transformer is: 125 kVA, rated 2.4% regulation at unity power factor.
- Phase imbalance 2% maximum.
- Maximum voltage variation at full load 6% (Including line impedance).
- Transients must be less than 1500V peak. (on a 380V line)
- A record of power input disturbances over a continuous two-weeks period (prior to delivery) enables determination of the frequency and degree of these disturbances and can be used to ascertain the need to provide line conditioning equipment.

GROUND SYSTEM

- System of equipotential grounding.
- Equipotential: The equipotential link will be by means of an equipotential bar. This equipotential bar should be connected to the protective earth conductors in the ducts of the non GE cableways and to additional equipotential connections linking up all the conducting units in the rooms where GE system units are located.
- The impedance of the earth bar should be less than or equal to 2 Ω (ohm).

CABLES

- Power and cable installation must comply with the distribution diagram.
- All cables must be isolated and flexible of HO7RNF type, cable color codes must comply with standards for electrical installation.
- The cables from signaling and remote control (Y,SEO,L...) will go to A1 Main Disconnect with a pigtail length of 1.5m, and will be connected during installation. Each conductor will be identified and isolated (screw connector).

CABLEWAYS

The general rules for laying cableways should meet the conditions laid down in current standards and regulations, with regard to:

- Protecting cables against water (cableways should be waterproof).
- Protecting cables against abnormal temperatures (proximity to heating pipes or ducts).
- Protecting cables against temperature shocks.
- Replacing cables (cableways should be large enough for cables to be replaced).
- Metal cableways should be grounded.

POWER DISTRIBUTION




Table2:


Feeder Table						
The information below assumes the use of copper wire, rated 75 C and run in steel conduit. All ampacity is determined in accordance with the National Electrical Code (NFPA 70), Table 310-16 (2002). The ampacity of the circuit protection device listed above determines the minimum feeder size, except where total source regulation limits require a larger size. If the wire size does not match the lists below, please select the nearest wire size as per to local standards.						
Feeder length from Power Substation to MDP - ft (m)	Minimum Wire Size, AWG or MCM (mm ²)/VAC					
	380 VAC	400 VAC	420 VAC	440 VAC	460 VAC	480 VAC
50 (15)	2 (35)	2 (35)	3 (30)	3 (30)	3 (30)	3 (30)
100 (30)	2 (35)	2 (35)	3 (30)	3 (30)	3 (30)	3 (30)
150 (46)	2 (35)	2 (35)	3 (30)	3 (30)	3 (30)	3 (30)
200 (61)	2 (35)	2 (35)	3 (30)	3 (30)	3 (30)	3 (30)
250 (76)	1 (45)	1 (45)	2 (35)	2 (35)	2 (35)	3 (30)
300 (91)	1/0 (50)	1/0 (50)	1 (45)	1 (45)	2 (35)	2 (35)
350 (107)	2/0 (70)	1/0 (50)	1/0 (50)	1 (45)	1 (45)	1 (45)
400 (122)	2/0 (70)	2/0 (70)	1/0 (50)	1/0 (50)	1/0 (50)	1 (45)
Sub-Feeder length from MDP to PDU - ft (m)						
32 (9.7536)	2 (35)	2 (35)	3 (30)	3 (30)	3 (30)	3 (30)
Grounding						
Run a dedicated 1/0 [50 mm ²] or larger insulated copper ground wire from the power source to the MDP and from MDP to the PDU. Run the ground wire in the same raceway with the three-phase wires.						

Notes :


- Wire size: 4x2mm² [14AWG] and 1x2mm² [14AWG] GND
- Power control cable: 3 m [10 ft], multi-conductor, 24V DC
- GE supplied MDP option E45021BB includes a 10 meter long power cable (HO7RN-F) with wire size 4x50mm² and a 50 meter long control cable with wire size 2x1.5mm²

TYPICAL CABLE MANAGEMENT

CONDUIT IN THE FLOOR




CONDUIT BELOW FLOOR




NOT TO SCALE

INTERCONNECTIONS



SCAN ROOM WARNING LIGHT AND DOOR INTERLOCK



Notes :

- (1) Wire size: 2mm² [14 AWG] at 24V
- (2) Door Interlock circuit is jumpered out if a door switch is not provided.
- (3) Grounding not shown on the detail, but must comply with local codes.

⁽¹⁾- Length based on sales configuration divided on short, medium and long options.



27/CR2 HEALTH CODE REVIEW
 SCALE: 1/8" = 1'-0"



HOSPITAL LICENSING RULES

- NUCLEAR MEDICINE SUITE
- (s)(1)(B) Radioisotope room (Hot Lab). When radiopharmaceutical preparation is performed on site, the room shall include sufficient space for equipment, storage of radionuclides, chemicals for preparation, dose calibrators, and record keeping. When prepared materials are used, storage and calculation area may be smaller than for on-site preparation.
 - (s)(1)(B)(i) The room and isotope handling areas within the room shall have appropriate radiation shielding.
 - (s)(1)(B)(ii) There shall be a shielded area or enclosed shielded cabinet for long-term storage of decaying radioisotopes.
 - (s)(1)(C) Positron emission tomography (PET). When Pet Services are provided, scanner and cyclotron rooms shall be in compliance with the manufacturer's recommendations and provide a minimum of three feet of clear and unobstructed working space on all sides of equipment accessible to staff and patient.
 - (s)(1)(C)(i) A control alcove shall be provided with a view window permitting view of the patient.
 - (s)(1)(C)(ii) An equipment area large enough to contain necessary electronic and electrical gear shall be provided.
 - (s)(1)(C)(iii) A dose administration room(s) with radiation shielding shall be located near treatment room. Patients in route to procedure rooms shall not pass through public corridors and waiting rooms after injection with radioisotope.
 - (s)(1)(C)(iv) A patient toilet with radiation shielding shall be provided with or adjacent to dose administration room(s). The patient toilet rooms shall contain a hand washing fixture with hands-free operable controls.
 - (s)(1)(D)(i) Patient waiting area. The area shall be out of traffic and under direct staff visual control. When the waiting area serves both outpatients and inpatients, separate areas shall be provided and include visual privacy between the waiting areas.
 - (s)(1)(D)(ii) Control desk and reception area. A control desk and reception area shall be provided.
 - (s)(1)(D)(iii) Dictation and report preparation area. The dictation and report preparation area may be incorporated with the control station.
 - (s)(1)(D)(iv) Holding Area. The holding area shall be under direct staff control, out of the direct line of traffic, and have space for stretchers. The holding area shall accommodate two stretchers for the first procedure room with one additional station for each additional procedure room.
 - (s)(1)(D)(v) Patient toilet facilities. A toilet room with a hand washing fixture with hands-free operable controls shall be provided convenient to the waiting room and procedure room.
 - (s)(1)(D)(vi) Staff toilet facilities. Toilets and hand washing fixtures with hands-free operable controls may be outside the suite but shall be convenient for staff office.
 - (s)(1)(D)(vii) Patient dressing rooms or cubicles. Dressing rooms or cubicles shall be provided convenient to the waiting areas and procedure rooms. Each room or cubicle shall include a seat or bench, a mirror, and provisions for hanging patients' clothing and for securing valuables. At least one dressing room shall be provided to accommodate a wheelchair.
 - (s)(1)(D)(xvii) Offices for physicians, oncologist, physicists, and assistants. Offices shall include provisions for individual consultation, viewing, and charting of film.
 - (s)(1)(D)(xviii) Clerical office(s) spaces. Clerical office(s) spaces shall be provided.
 - (s)(1)(D)(xix) Consultation room. A consultation room shall be provided.
 - (s)(1)(D)(xx) Clean storage room. A clean storage room shall be provided for clean supplies and linens. A hand washing fixture shall be provided with hands-free operable controls. When conveniently located, the clean storage room may be shared with another.
 - (s)(1)(D)(xai) Soiled workroom. The soiled workroom shall not have direct connection to the nuclear medicine procedure or diagnostic rooms and sterile activity rooms. The room shall contain a clinical sink or equivalent flushing type fixture, work counter, hand washing fixture with hands-free operable controls, waste receptacle, and soiled linen receptacle. When contaminated soiled material or fluid waste is not handled, only a soiled holding room is required.
 - (s)(1)(D)(xaii) Housekeeping room. The housekeeping room shall be located within the suite.
 - (s)(2)(A)(i) Radiation protection shall be designed, tested and approved by a medical physicist licensed under the Texas Medical Physics Practice Act, Occupations Code Chapter 602.
 - (s)(2)(B)(i) Flooring used in the nuclear medicine procedure room, any work or treatment areas where radioactive material is handled, and soiled workroom shall be of the seamless monolithic type as required by §133.162(d)(2)(B)(ii)(I) of this title.
 - (s)(2)(B)(ii) Ceilings in radiopharmacy, hot laboratory, and soiled workrooms shall be monolithic as required by §133.162(d)(2)(B)(ii)(II) of this title.

CONDRAY
 DESIGN GROUP
 ARCHITECTURE
 & INTERIOR DESIGN
 3708 UPLAND AVE.
 LUBBOCK, TX 79407
 806.748.6190
 condray.com



FINCHER
 ENGINEERING, LLC
 FINCHER ENGINEERING, LLC
 TX FIRM #F-16408
 5621 114TH ST., SUITE 100
 LUBBOCK, TX 79424
 PH: 806-701-5109
 WWW.FINCHERENG.COM

Nieman Engineering, LLC
 1500 Broadway St, Suite 1210
 Lubbock, Texas 79401
 T: 806-589-3340 TPPE Firm
 Registration No: F-14148


BSA HOSPITAL
 PET/CT INFILL
 1600 WALLACE BLVD
 AMARILLO, TEXAS
 79106

REVISIONS:
 Δ 03/21/2025

COPYRIGHT © 2025 CONDRAY DESIGN GROUP, INC. THESE DRAWINGS, OR PARTS THEREOF, MAY NOT BE REPRODUCED IN ANY FORM, BY ANY METHOD, FOR ANY PURPOSE, WITHOUT PRIOR WRITTEN CONSENT FROM CONDRAY DESIGN GROUP, INC.

PROJECT NO. 22418
 DATE: 03/14/2025

SHEET NO.
CR2
 2 OF 2





27/A2 DIMENSION PLAN
SCALE: 1/8" = 1'-0"

GENERAL NOTES


- ALL DIMENSIONS ARE ACTUAL DIMENSIONS TO FACE OF METAL STUDS, OR FACE OF EXISTING WALL FINISH UNLESS NOTED OTHERWISE.
- FIELD VERIFY ALL DIMENSIONS, NEW OR EXISTING, PRIOR TO CONSTRUCTION AND ADJUST WHERE REQUIRED TO PROVIDE A PROPER AND COMPLETE INSTALLATION. NOTIFY THE ARCHITECT OF ANY DISCREPANCIES WITH EXISTING OR NEW CONDITIONS.
- CONTRACTOR SHALL COORDINATE ALL LAYOUT WORK WITH EQUIPMENT MANUFACTURER'S DIMENSIONAL REQUIREMENTS. THIS INCLUDES CONTRACTOR AND OWNER PROVIDED EQUIPMENT.
- * = 3 5/8" MTL. STUDS @ 16" O.C.
- THE STRUCTURAL, MECHANICAL AND ELECTRICAL DRAWINGS ARE SUPPLEMENTARY TO THE ARCHITECTURAL DRAWINGS. SHOULD THERE BE A DISCREPANCY BETWEEN THE ARCHITECTURAL DRAWINGS AND THE CONSULTANT DRAWINGS, SUCH DISCREPANCY IS TO BE BROUGHT TO THE ATTENTION OF THE ARCHITECT AND THE CONTRACTOR SHALL RECEIVE INSTRUCTION PRIOR TO INSTALLATION OR PERFORMANCE OF SAID WORK. ANY WORK PERFORMED IN CONFLICT WITH THE DRAWINGS SHALL BE CORRECTED BY THE CONTRACTOR AT HIS OWN EXPENSE.
- ALL CONSTRUCTION SHALL COMPLY WITH APPLICABLE ACCESSIBILITY CODE REQUIREMENTS. THE CONTRACTOR SHALL BE AWARE OF ALL DIMENSIONALLY CRITICAL AREAS AND COMPLY WITH APPLICABLE STANDARDS. IF THERE ARE ANY DISCREPANCIES, THESE ARE TO BE BROUGHT TO THE ARCHITECT'S ATTENTION IMMEDIATELY.
- AT ALL NEW FLOOR DRAIN LOCATIONS, THE SLAB IS TO BE RECESSED AND SLOPED FOR POSITIVE DRAINAGE. UNLESS NOTED OTHERWISE, SLOPE IS TO BE 1/8" x 1'-0" WITH A 1/4" x 3/8" OVERALL RECESS. EXISTING SLABS ARE TO BE CHIPPED OUT TO ACCOMMODATE.
- ALL WALLS ARE TO BE PARTITION TYPE 'P1' UNLESS NOTED OTHERWISE.

KEYED NOTES


- DESIGNATED BY:
- THIS WALL TO RECEIVE (2) LAYERS OF 3/4" LEAD-LINED PLYWOOD WITH 1/2" LEAD SHEET (1" TOTAL LEAD) ON THE ROOM SIDE OF THE WALL UP TO 8'-0" A.F.F. RUN LEAD LINING CONTINUOUSLY WHERE PERPENDICULAR WALLS ABUT. ABOVE 8'-0", INSTALL 2 1/2" FURRING STUDS. INSTALL 5/8" GYPSUM BOARD ON BOTH OUTSIDE FACES OF THE WALL. REFER TO STRUCTURAL FOR WALL FRAMING.
 - THIS WALL TO RECEIVE (2) LAYERS OF 3/4" LEAD-LINED PLYWOOD WITH 1/2" LEAD SHEET (1" TOTAL LEAD) ON THE ROOM SIDE OF THE WALL UP TO 8'-0" A.F.F. RUN LEAD LINING CONTINUOUSLY WHERE PERPENDICULAR WALLS ABUT. ABOVE 8'-0", INSTALL 2 1/2" FURRING STUDS. INSTALL 5/8" GYPSUM BOARD ON NEW OUTSIDE FACE OF THE WALL. REFER TO STRUCTURAL FOR WALL FRAMING. NEW FRAMING TO RUN PARALLEL ON THE INSIDE OF EXISTING WALL FRAMING.
 - THIS WALL TO RECEIVE (2) LAYERS OF 3/4" LEAD-LINED PLYWOOD WITH 1/2" LEAD SHEET (1" TOTAL LEAD) ON THE ROOM SIDE OF THE WALL UP TO 8'-0" A.F.F. RUN LEAD LINING CONTINUOUSLY WHERE PERPENDICULAR WALLS ABUT. ABOVE 8'-0", INSTALL 2 1/2" FURRING STUDS. INSTALL 3 5/8" FURROUT WALL IN FRONT OF LEAD-LINED WALL FOR PLUMBING CHASE. INSTALL 5/8" GYPSUM BOARD ON NEW OUTSIDE FACE OF THE WALL. REFER TO STRUCTURAL FOR WALL FRAMING.
 - THIS FACE OF THIS WALL TO RECEIVE (1) LAYERS OF 5/8" LEAD-LINED GYPSUM BOARD WITH 1/8" LEAD SHEET. RUN LEAD-LINING CONTINUOUS AND WRAP BEHIND ANY MEMBRANE PENETRATIONS WITH LEAD. REFER TO RADIATION PROTECTION SPECIFICATIONS FOR REQUIREMENTS.
 - THIS FACE OF THIS WALL TO RECEIVE (1) LAYERS OF 1/2" LEAD-LINED PLYWOOD WITH 1/4" LEAD SHEET. INSTALL 5/8" GYPSUM BOARD OVER THIS. RUN LEAD-LINING CONTINUOUS AND WRAP BEHIND ANY MEMBRANE PENETRATIONS WITH LEAD. REFER TO RADIATION PROTECTION SPECIFICATIONS FOR REQUIREMENTS.
 - THIS FACE OF THIS WALL TO RECEIVE (1) LAYERS OF 5/8" LEAD-LINED GYPSUM BOARD WITH 1/16" LEAD SHEET. RUN LEAD-LINING CONTINUOUS AND WRAP BEHIND ANY MEMBRANE PENETRATIONS WITH LEAD. REFER TO RADIATION PROTECTION SPECIFICATIONS FOR REQUIREMENTS.
 - ALIGN FINISHES.
 - 4" SHAFTWALL FRAMING WITH 2 HOUR FIRE RATED CONSTRUCTION FROM THE SLAB TO ROOF STRUCTURE ABOVE. SHAFT SHALL BE SIZED APPROPRIATELY TO CONTAIN INSULATED MECHANICAL DUCTS WITH MIN. 8" CLEARANCE ON ALL SIDES. ALL JOINTS AND PENETRATIONS TO BE SEALED WITH UL RATED SYSTEMS FOR A COMPLETE ASSEMBLY.



16/A2 ENLARGED PLAN
SCALE: 1/4" = 1'-0"



12/A2 ENLARGED PLAN
SCALE: 1/4" = 1'-0"



08/A2 TYPICAL FRAME BACKSET
SCALE: 1 1/2" = 1'-0"

CONDRA Y
DESIGN GROUP
ARCHITECTURE & INTERIOR DESIGN
3708 UPLAND AVE.
LUBBOCK, TX 79407
806.748.6190
condray.com


REGISTERED ARCHITECT
ALAN KOPPEL
STATE OF TEXAS
2110
03/29/2025

FINCHER
ENGINEERING, LLC
FINCHER ENGINEERING, LLC
TX FIRM #F-16408
5621 114TH ST., SUITE 100
LUBBOCK, TX 79424
PH: 806-701-5109
WWW.FINCHERENG.COM

Nieman Engineering, LLC
1500 Broadway St, Suite 1210
Lubbock, Texas 79401
T: 806-589-3340 TBPPE Firm
Registration No: F-14148

BSA HOSPITAL
PET/CT INFILL
1600 WALLACE BLVD
AMARILLO, TEXAS
79106

REVISIONS:
03/21/2025
COPYRIGHT © 2025 CONDRA Y DESIGN GROUP, INC. THESE DRAWINGS, OR PARTS THEREOF, MAY NOT BE REPRODUCED IN ANY FORM, BY ANY METHOD, FOR ANY PURPOSE, WITHOUT PRIOR WRITTEN CONSENT FROM CONDRA Y DESIGN GROUP, INC.
PROJECT NO. 22418
DATE: 03/14/2025
SHEET NO.
A2
2 OF 8




GENERAL NOTES

- 1) ON ALL WALLS SCHEDULED TO REMAIN. PATCH ANY EXISTING HOLES, CRACKS, OR OTHERWISE DAMAGED AREAS AND RE-TEXTURE AND PAINT AS SCHEDULED.
- 2) THE STRUCTURAL, MECHANICAL, PLUMBING AND ELECTRICAL DRAWINGS ARE SUPPLEMENTARY TO THE ARCHITECTURAL DRAWINGS. SHOULD THERE BE A DISCREPANCY BETWEEN THE ARCHITECTURAL DRAWINGS AND THE CONSULTANT DRAWINGS, SUCH DISCREPANCY IS TO BE BROUGHT TO THE ATTENTION OF THE ARCHITECT AND THE CONTRACTOR SHALL RECEIVE INSTRUCTION PRIOR TO INSTALLATION OR PERFORMANCE OF SAID WORK. ANY WORK PERFORMED IN CONFLICT WITH THE DRAWINGS SHALL BE CORRECTED BY THE CONTRACTOR AT HIS OWN EXPENSE.
- 3) REFER TO PROJECT MANUAL FOR ROOM FINISH SCHEDULE.
- 4) ALL NEW WALLS TO RECEIVE FULL BATT INSULATION FROM FLOOR TO THE FULL HEIGHT OF THE WALL, INCLUDING ABOVE CEILING.

KEYED NOTES

- DESIGNATED BY: 1
- 1) NO WORK IN THIS AREA.
 - 2) PET/CT EQUIPMENT. REFER TO MPE AND/OR VENDOR DRAWINGS FOR MORE INFORMATION.
 - 3) WALL MOUNTED FLAT SCREEN T.V. OWNER FURNISHED, CONTRACTOR INSTALLED. INSTALL MIN. 24"x24" AREA OF 3/4" PLYWOOD BLOCKING IN WALL. COORDINATE EXACT LOCATION WITH OWNER.
 - 4) INSTALL .36" HIGH BY 16" WIDE SECTION OF 3/4" IN-WALL BLOCKING STARTING AT 36" A.F.F. FOR WALL MOUNTED BRACKET FOR COMPUTER AND MONITOR TO BE PROVIDED AND INSTALLED BY OTHERS.
 - 5) ACCESS CONTROL CARD READER. REFER TO ELECTRICAL.
 - 6) ACCESS CONTROL CARD READER CONNECTED TO POWER OPERATOR. REFER TO ELECTRICAL AND DOOR HARDWARE SCHEDULE.
 - 7) REFRIGERATOR. OWNER FURNISHED AND INSTALLED.
 - 8) 12"x12" LEAD-LINED, STAINLESS-STEEL PASS-THROUGH BOX WITH 1/4" LEAD-LINING.
 - 9) CONTRACTOR TO PROVIDE APPROPRIATE TPO SYSTEM DETAILS TO FLASH IN NEW CURES AND PATCH BACK MATERIALS AS REQUIRED AT NEW ROOF PENETRATIONS.
 - 10) INFILL ABANDONED OPENING WITH CRASHRAIL TO MATCH EXISTING FOR A CONTINUOUS RUN.
 - 11) ACCESSIBLE CHANGING BENCH. OWNER PROVIDED, CONTRACTOR INSTALLED. BENCH SHALL BE ATTACHED TO THE WALL WITH A METAL BRACKET.
 - 12) ACCESSIBLE LOCKER. OWNER PROVIDED, CONTRACTOR INSTALLED.
 - 13) CONTRACTOR SHALL PROVIDE ALL PLUMBING FIXTURES INDICATED IN THIS ROOM ON PLUMBING PLAN SHEETS AND DELIVER THOSE MATERIALS TO THE OWNER. ALL PLUMBING ROUGH-IN, INCLUDING SINK CARRIER, IN THIS ROOM SHALL BE INSTALLED AS INDICATED AND CAPPED IN THE WALL. ALL TOILET ACCESSORIES SCHEDULED FOR THIS ROOM SHALL BE PROVIDED AND DELIVERED TO THE OWNER.

27/A3 ANNOTATED PLAN
SCALE: 1/8" = 1'-0"



FLOOR PLAN LEGEND

- NEW DOOR - REFER TO DOOR SCHEDULE
- WINDOW DESIGNATION - REFER TO FRAME SCHEDULE
- NEW FIRE EXTINGUISHER AS SPECIFIED

CONDRA Y
DESIGN GROUP
ARCHITECTURE & INTERIOR DESIGN
3708 UPLAND AVE.
LUBBOCK, TX 79407
806.748.6190
condray.com



FINCHER
FINCHER ENGINEERING, LLC
TX FIRM #F-16408
5621 114TH ST., SUITE 100
LUBBOCK, TX 79424
PH: 806-701-5109
WWW.FINCHERENG.COM

Nieman Engineering, LLC
1500 Broadway St, Suite 1210
Lubbock, Texas 79403
T: 806-589-3340 TBPE Firm
Registration No: F-14148


BSA HOSPITAL
PET/CT INFILL
1600 WALLACE BLVD
AMARILLO, TEXAS
79106

REVISIONS:
A 03/21/2025
COPYRIGHT © 2025 CONDRA Y DESIGN GROUP, INC. THESE DRAWINGS, OR PARTS THEREOF, MAY NOT BE REPRODUCED IN ANY FORM, BY ANY METHOD, FOR ANY PURPOSE, WITHOUT PRIOR WRITTEN CONSENT FROM CONDRA Y DESIGN GROUP, INC.
PROJECT NO. 22418
DATE: 03/14/2025

SHEET NO.
A3
3 OF 8


KEYED NOTES

- DESIGNATED BY:
- 1 SOAP DISPENSER WITH CONTROLS MOUNTED @ 47" A.F.F. OWNER FURNISHED, CONTRACTOR INSTALLED.
 - 2 PAPER TOWEL DISPENSER WITH CONTROLS MOUNTED @ 47" A.F.F. OWNER FURNISHED, CONTRACTOR INSTALLED.
 - 3 UNDERCABINET LIGHT FIXTURE. REFER TO ELECTRICAL DRAWINGS.
 - 4 UNDERCOUNTER RAKKS SUPPORT BRACKET AS SPECIFIED.
 - 5 REMOVABLE ACCESS PANEL. FINISH AS SCHEDULED.
 - 6 PROVIDE CAM LOCK AS SPECIFIED. TYPICAL FOR ALL LOCATIONS INDICATED WITH SYMBOL.
 - 7 REFRIGERATOR. OWNER FURNISHED, CONTRACTOR INSTALLED.
 - 8 BASE AS SCHEDULED.
 - 9 PAINTED GYPSUM BOARD FURROWDOWN.
 - 10 MED GAS OUTLETS. REFER TO MPE FOR MORE INFORMATION.
 - 11 NURSE CALL. REFER TO MPE FOR MORE INFORMATION.
 - 12 STAINLESS STEEL COUNTERTOPS AND BACKSPLASH AS SPECIFIED.
 - 13 FIELD VERIFY SPACE REQUIRED FOR EXISTING EQUIPMENT AND ADJUST MILLWORK LENGTH TO ACCOMMODATE.
 - 14 CLOSURE PANEL AT OPEN ALCOVE. OPEN ALCOVE IS FOR OWNER PROVIDED MATERIALS STORAGE CABINET. CONFIRM SIZE OF ALCOVE.
 - 15 12"x12" LEAD-LINED, STAINLESS-STEEL PASS-THROUGH BOX WITH 1/4" LEAD-LINING.
 - 16 EQUIPMENT - OWNER FURNISHED, OWNER INSTALLED.
 - 17 WALL PROTECTION PANELS ON THIS WALL SHALL BE IN THE HATCHED AREAS.




25/A6 MILLWORK ELEVATION
 SCALE: 3/8" = 1'-0"

SCAN ROOM 123




13/A6 MILLWORK ELEVATION
 SCALE: 3/8" = 1'-0"

STAFF ROOM 107




05/A6 MILLWORK ELEVATION
 SCALE: 3/8" = 1'-0"

RECEPTION 102




18/A6 MILLWORK ELEVATION
 SCALE: 3/8" = 1'-0"

CONTROL ROOM 122




06/A6 MILLWORK ELEVATION
 SCALE: 3/8" = 1'-0"

RECEPTION 102




19/A6 MILLWORK ELEVATION
 SCALE: 3/8" = 1'-0"

HOT LAB 116




15/A6 MILLWORK ELEVATION
 SCALE: 3/8" = 1'-0"

HOT LAB 116




07/A6 MILLWORK ELEVATION
 SCALE: 3/8" = 1'-0"

RECEPTION 102




16/A6 MILLWORK ELEVATION
 SCALE: 3/8" = 1'-0"

DOSE ROOMS AND CLEAN STORAGE




08/A6 MILLWORK ELEVATION
 SCALE: 3/8" = 1'-0"


HOLDING ROOMS




21/A8 HEAD DETAIL
SCALE: 1 1/2" = 1'-0"




17/A8 HEAD DETAIL
SCALE: 1 1/2" = 1'-0"




13/A8 HEAD DETAIL
SCALE: 1 1/2" = 1'-0"




09/A8 HEAD DETAIL
SCALE: 1 1/2" = 1'-0"




22/A8 JAMB DETAIL
SCALE: 1 1/2" = 1'-0"




18/A8 JAMB DETAIL
SCALE: 1 1/2" = 1'-0"




14/A8 JAMB DETAIL
SCALE: 1 1/2" = 1'-0"




10/A8 JAMB DETAIL
SCALE: 1 1/2" = 1'-0"




23/A8 SILL DETAIL
SCALE: 1 1/2" = 1'-0"




19/A8 SILL DETAIL
SCALE: 1 1/2" = 1'-0"




15/A8 SILL DETAIL
SCALE: 1 1/2" = 1'-0"



11/A8 SILL DETAIL
SCALE: 1 1/2" = 1'-0"



20/A8 TYPICAL DOOR FRAMING
SCALE: NOT TO SCALE





12/A8 TYPICAL CONTROL JOINT DETAILS
SCALE: NOT TO SCALE

DOOR SCHEDULE

DOOR MARK	OPENING	DOOR TYPE	PAIR	DOOR MATERIAL	FIRE RATING	FRAME TYPE	DETAILS			REMARKS
							HEAD	JAMB	SILL	
101A	3'-8" x 7'-0"	A	-	SCPL	-	HM3	09/AB	10/AB	11/AB	-
103A	3'-0" x 7'-0"	A	-	SCPL	-	HM1	09/AB	10/AB	11/AB	-
104A	3'-0" x 7'-0"	A	-	SCPL	-	HM1	09/AB	10/AB	11/AB	-
105A	3'-0" x 7'-0"	A	-	SCPL	-	HM1	09/AB	10/AB	11/AB	-
106A	3'-0" x 7'-0"	A	-	SCPL	-	HM1	09/AB	10/AB	11/AB	-
107A	3'-0" x 7'-0"	A	-	SCPL	-	HM1	09/AB	10/AB	11/AB	-
108A	3'-8" x 7'-0"	A	-	SCPL	-	HM1	09/AB	10/AB	11/AB	ACCESS CONTROL
109A	3'-6" x 7'-0"	A	-	SCPL	-	HM1	09/AB	10/AB	11/AB	-
110A	3'-6" x 7'-0"	A	-	SCPL	-	HM1	09/AB	10/AB	11/AB	-
111A	3'-0" x 7'-0"	D	-	SCPL	-	HM1	09/AB	10/AB	11/AB	-
112A	3'-8" x 7'-0"	B	-	SCPL	-	HM2	13/AB	14/AB	15/AB	LEAD-LINED
113A	3'-8" x 7'-0"	B	-	SCPL	-	HM2	13/AB	14/AB	15/AB	LEAD-LINED
114A	3'-6" x 7'-0"	A	-	SCPL	-	HM2	13/AB	14/AB	15/AB	LEAD-LINED
115A	3'-8" x 7'-0"	B	-	SCPL	-	HM2	13/AB	14/AB	15/AB	LEAD-LINED
116A	3'-6" x 7'-0"	B	-	SCPL	-	HM2	13/AB	14/AB	15/AB	LEAD-LINED, ACCESS CONTROL
117A	3'-8" x 7'-0"	B	-	SCPL	-	HM2	13/AB	14/AB	15/AB	LEAD-LINED
118A	3'-6" x 7'-0"	B	-	SCPL	-	HM2	13/AB	14/AB	15/AB	LEAD-LINED
119A	3'-8" x 7'-0"	B	-	SCPL	-	HM2	13/AB	14/AB	15/AB	LEAD-LINED
120A	3'-8" x 7'-0"	B	-	SCPL	-	HM2	13/AB	14/AB	15/AB	LEAD-LINED
121A	7'-4" x 7'-0"	A	PR	SCPL	-	HM1	09/AB	10/AB	11/AB	ACCESS CONTROL
122A	3'-0" x 7'-0"	B	-	SCPL	-	HM2	13/AB	14/AB	15/AB	LEAD-LINED, ACCESS CONTROL
123A	7'-0" x 7'-0"	C	PR	SCPL	-	HM2	13/AB	14/AB	15/AB	LEAD LINED UNEQUAL PAIR-4' & 3'
123B	3'-0" x 7'-0"	B	-	SCPL	-	HM2	13/AB	14/AB	15/AB	LEAD-LINED
124A	4'-0" x 7'-0"	A	-	SCPL	-	HM1	09/AB	10/AB	11/AB	-

HM = HOLLOW METAL SCPL = SOLID CORE PLASTIC LAMINATE
LEAD LINED DOORS ARE TO MATCH ADJACENT WALL LEAD THICKNESS.



CONDRA Y
DESIGN GROUP
ARCHITECTURE & INTERIOR DESIGN
3708 UPLAND AVE.
LUBBOCK, TX 79407
806.748.6190
condray.com

REGISTERED ARCHITECT
STATE OF TEXAS
03/21/2025


FINCHER
ENGINEERING, LLC
FINCHER ENGINEERING, LLC
TX FIRM #F-16408
5621 114TH ST., SUITE 100
LUBBOCK, TX 79424
PH: 806-701-5109
WWW.FINCHERENG.COM

Nieman Engineering, LLC
1500 Broadway St, Suite 1210
Lubbock, Texas 79403
T: 806-589-3340 TPBE Firm
Registration No: F-14148

BSA HOSPITAL
PET/CT INFILL
1600 WALLACE BLVD
AMARILLO, TEXAS
79106

REVISIONS:
03/21/2025
COPYRIGHT © 2025 CONDRA Y DESIGN GROUP, INC. THESE DRAWINGS, OR PARTS THEREOF, MAY NOT BE REPRODUCED IN ANY FORM, BY ANY METHOD, FOR ANY PURPOSE, WITHOUT PRIOR WRITTEN CONSENT FROM CONDRA Y DESIGN GROUP, INC.
PROJECT NO. 22418
DATE: 03/14/2025

SHEET NO.
A8
8 OF 8




*** Please note that this drawing indicates the MINIMUM amount of temporary barriers that will be required. Additional barriers and measures may be required for the Contractor to meet the requirements for Project Containment and Infection Controls Standards. Contractor shall be responsible for ALL required temporary materials and measures taken.

*** All Contractor parking shall be on the lower level of the parking structure where designated by the Owner. No surface level parking in front of the Hospital will be allowed.

NOTE: THIS DOCUMENT IS RELEASED FOR THE PURPOSE OF COORDINATION UNDER THE AUTHORITY OF: GRANT KOERTNER, #21110, ON 03/27/2025. NOT FOR REGULATORY APPROVAL, PERMITTING, OR CONSTRUCTION.

LARGER VEHICLES CAN OFFLOAD EQUIPMENT AND/OR MATERIALS AT THE RECEIVING DOCK AT GROUND LEVEL TO BE BROUGHT DOWN VIA ELEVATOR INTO THE MECHANICAL ROOM (SEE TRAVEL PATH).



**BSA HOSPITAL
PET/CT INFILL EQUIPMENT AND MATERIAL TRAVEL PATH TO MECHANICAL ROOM.**

SCALE: NO SCALE
CONDRA Y DESIGN GROUP, INC.

NOTE: THIS DOCUMENT IS RELEASED FOR THE PURPOSE OF COORDINATION UNDER THE AUTHORITY OF: GRANT KOERTNER, #21110, ON 03/27/2025. NOT FOR REGULATORY APPROVAL, PERMITTING, OR CONSTRUCTION.

PROJ. NO. 22418
DATE: 03/27/2025



ADDENDUM #1

Page 1 of 1

March 27, 2025

BSA Hospital PET/CT Infill
1600 Wallace Blvd
Amarillo, TX



NOTICE TO BIDDERS:

The following shall be incorporated in and become a part of the original Drawings and Specifications of the above identified project. Please acknowledge receipt of this Addendum by noting it on your Proposal.

Electrical Items:

Item 1. Drawing Sheet E3:

- a. Receptacle and data outlet serving EMR shall be relocated to adjacent wall near TV. Coordinate exact device locations with EMR equipment and architect.
- b. Provide 120v circuit to serve new fire alarm equipment, power supplies, batteries, etc. Extend and connect to nearest 120v "life safety" emergency panel with available capacity. Coordinate location with fire alarm contractor.

Item 2. Drawing Sheet E4:

- a. EF-1, EF-2, AHU-1, and CU-1 shall be connected to panel "ERHZA" in 1st floor electrical room near gift shop.
- b. Provide extension of existing lightning protection system for coverage of new roof mounted HVAC equipment. Contractor shall provide and install air terminals, conductors, terminations, conduit, and connectors for complete system as required by NFPA 780 and UL96A. Lightning protection system shall match existing. Lightning protection contractor shall provide "Letter of Findings" certificate/UL master label as required by NFPA 780 and UL96A. Field verify existing conditions

End of Fincher Engineering, LLC Addendum

Fincher Engineering, LLC
TX Firm #F-16408
5621 114th St., Suite 100, Lubbock, TX 79424
Ph: (806)701-5109 www.finchereng.com